

## VEEV inPRIME™



This is the safety alert symbol. It is used to alert you to potential physical injury hazards.

### ENGLISH

**SAFETY WARNINGS AND INSTRUCTIONS PLEASE READ ALL SAFETY WARNINGS AND INSTRUCTIONS BEFORE USE TO AVOID INJURY.** These safety warnings and instructions cannot cover all possible conditions that could occur, and users should exercise care and caution.

**KEEP THESE SAFETY WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE AS THEY CONTAIN IMPORTANT INFORMATION.** These Safety Warnings and Instructions are applicable to VEEV inPRIME™ device and pod.

See [www.veev-vape.com](http://www.veev-vape.com) for any updates to these Safety Warnings and Instructions.

### INTENDED USERS

- This product is for adult use only. Children and adolescents should never use this product.
- This product is for adults who would otherwise continue to smoke or use other nicotine-containing products.
- This product should not be used by persons with reduced physical, sensory or mental capabilities or lack of knowledge unless they have been given supervision or instruction to use the product in a safe way and understand the hazards involved.

### NICOTINE

- This product provides nicotine, which is addictive.
- This product is not risk-free. The best way to reduce nicotine-related health risks is to quit nicotine use altogether.
- Some users may experience side effects including: abdominal pain, cough, dizziness, dry mouth,

headache,  
malaise, nasal stuffiness,  
nausea, mouth irritation, throat  
irritation, vomiting.

- Nicotine-containing products should not be used by people who have or are at risk of heart diseases, are diabetic, are epileptic, or are experiencing seizures. Nicotine-containing products should not be used during pregnancy or while breastfeeding. If you are pregnant, breastfeeding or think you may be pregnant, you should quit nicotine use altogether. Stopping smoking or switching to this product or other nicotine-containing products may require the adjustment of the dosing of certain medicines (e.g. theophylline, clozapine, ropinirole). If you have questions about whether you should use this product given an existing health condition, you should consult a health care professional.

### **IMPORTANT SAFETY INFORMATION**

#### **WARNING**

#### **CHOKING AND INGESTION HAZARD**

- Keep this product out of reach of children and pets at all times.
- **CHOKING HAZARD** – This product and its accessories contain small parts.
- **INGESTION HAZARD** – If e-liquid is ingested, rinse mouth and seek medical attention immediately due to risk of nicotine intoxication.

#### **WARNING**

#### **ELECTRICAL HAZARDS**


Failure to follow these Safety Warnings and Instructions could result in fire, explosion, electric shock,

injury, or damage to the product or other property:

- Do not use this product where the use of electronic devices is prohibited.

Do not charge or use this product or accessories if damaged, tampered with or broken.

Do not use this product if the battery appears to be leaking.

Only charge this product indoors, as indicated by symbol  using Safety Extra Low Voltage with a 5V; 2A output.

Use a certified Power Adaptor and Charging Cable that are either supplied in the box or from a reputable source.

Refer to the 'Technical Data' section for Charging Cable and Power Adaptor compatibility details.

Do not use, charge, or store this product in places with high temperatures (such as inside a car in summer, or near heat sources such as radiators or fireplaces).

- Do not use this product where flammable materials, liquids or gases are present.

- This product and its accessories should not be exposed to any liquid. Do not touch them if they become wet or have been immersed in any liquid.

- Do not clean the device while on. Do not use cleaning agents on this product.

- Clean the USB charging port periodically to avoid accumulation of foreign matters (such as dust particles) and inspect USB port for foreign materials before using USB connector.

- Handle with care. Do not drop this product or subject it to strong shock.

- This product contains no user-serviceable parts. Do not attempt to open, modify, service, disassemble or repair any component of this product or to replace any of the components or batteries.

- Do not use this product if it has been exposed

to excessive cold, heat, or moisture.

- Do not touch this product or its accessories if they overheat, spark, fume, ignite, or burn. If applicable and possible, use caution to shut off or disconnect power supply.
- Never dispose of this product and its accessories with other household waste.



**WARNING**

**BATTERY RISKS**

This product is powered with sealed Lithium-ion (Li-ion) batteries. If you notice that battery fluid leaks, follow these precautions:

- If fluid from leaked battery is swallowed, seek medical attention immediately. Do not induce vomiting or ingest food or drink.
- If vapor from leaked battery is inhaled, get fresh air and seek medical attention as needed.

- If fluid from battery is in contact with skin, wash the affected area, including hands and do not touch eyes.

- If fluid from leaked battery is in contact with eyes, immediately flush with clean running water for at least 15 minutes and seek medical attention immediately.



**WARNING**

**IRRITATION RISKS**

Avoid e-liquid contact with skin and eyes. In the event of:

- Skin contact: wash immediately with soap and water.
- Eye contact: rinse carefully with water for several minutes.
- Contaminated clothing: wash before reuse.



## CAUTION

### **ALLERGIC REACTION RISKS**

- Using this product could cause an allergic reaction, such as swelling of the face, lips, tongue, gums, throat, or body, difficulty breathing, or wheezing.
- Stop using this product and seek medical attention immediately if you experience any of the symptoms above as they may indicate a serious allergic reaction.

### **USAGE AND STORAGE**

- Only use VEEV inPRIME™ pods specifically designed for this product. Never use this product with other pods. Doing so may cause injury.
- Do not modify or attempt to refill pods in any way or add any substance to the pods. Doing so may cause injury.
  - Use pods promptly once removed from original packaging.

- Store in a dry and clean place at room temperature.
- It is recommended to operate this product in temperatures between  $>0^{\circ}\text{C}/<30^{\circ}\text{C}$  and avoid rapid temperature changes.
- For an optimal experience and due to risk of leakage, only use this product in an upright orientation.
- Droplets or traces of liquid may appear during usage, storage, or unpacking of the pods. Should you see droplets or traces of liquid on a pod or device, without signs of leakage, carefully and thoroughly wipe the residue before use with a dry cloth (including the mouthpiece). Do not use the pod if it is actively leaking, or if any droplets or traces of liquid reappear after cleaning.
- Do not use this product if the pod appears to be damaged, tampered with, broken, or leaking.

- Due to the risk of the pods leaking with altitude changes, it is not recommended to fly with pods that have been removed from original packaging or have been partially used.

### **REPORTING OF ADVERSE EVENTS OR INCIDENTS**

- If you experience any unwanted health effect when using this product, consult a health care professional.
- You can report any adverse event or incident directly by contacting your local Customer Care. By reporting side effects, you can help provide more information on the safety of this product.
- For more information, please go to [www.veev-vape.com](http://www.veev-vape.com).

### **TECHNICAL DATA**

Model M0036

Battery type: Li-ion  
rechargeable battery

Input: 5V  2A

#### **Compatible Power Adaptor Information (not included in the box)**

Model: S52A21, S21A20, S21A22, S21A23,  
S21A25, S21A27, S00120, S00121, S00122,  
S00123, S00125, S00126, S00129, S82A40  
S82A41, S82A42, S82A43, S82A45, S82A4

Input: 100 V-240 V~ 50/60 Hz 0.3 A

Output: 5.0V  2.0A

#### **Compatible Charging Cable Information**

Type C to type C

Type A to type C

## INFORMATION FOR DISPOSAL

### Valid across European Union and EEA



This symbol on the product or on its packaging indicates that this product and its individual parts (including batteries) must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by bringing it to a designated collection point for the recycling of waste electrical and electronic equipment. The waste equipment can be returned free of charge to the point of sale in case of supply of a new electrical and electronic equipment. The waste equipment can be returned in any case free of charge to points of sale where the sales area for electrical and electronic equipment (“EEE”) is at least 400 square meters. The separate collection and recycling of your waste equipment (including batteries) at

the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. Disposing of waste equipment as unsorted municipal waste (e.g., by waste incineration or land filling) can have negative effects on the environment and human health. Owners of waste equipment can hand them in, within the framework of the possibilities, for the return or collection of waste equipment provided by public waste management authorities, so that a correct disposal of the old devices is ensured. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your local household waste disposal service or the shop where you purchased the product. The local importer of the product will provide for the financing of the treatment and recycling of waste equipment returned

through  
these designated collection  
points in accordance with local  
requirements.

E.E.E. Register n: IT16060000009351

### **BATTERY REMOVAL INSTRUCTIONS (FOR DISPOSAL AND RECYCLING)**

Batteries must not be removed by the consumer. At end of product life, only an authorized recycler may safely remove batteries by following the steps below.

#### **MODEL M0036**

- 1:** Check the voltage. The Device should be fully discharged before disassembling.
- 2:** Remove the half module from housing by pushing from USB port.
- 3:** Remove the Kapton Tape and the Button Holder.
- 4:** Unplug the battery FPC connector.

- 5:** Remove the battery FPC stick from the battery holder.
- 6:** Take out battery by lifting it up.

### **CONFIRMATION OF COMPLIANCE**

Designed and manufactured under the authority of Philip Morris Products S.A., Quai Jeanrenaud 3, 2000 Neuchâtel, Switzerland.

© 2024 Copyright  
Philip Morris Products S.A.

